



Socket assembly adjustable on lamp rod and mounting strap for ideal lamp height

**Socket (lamp) height adjustment options:**

- Rotate threaded brass lamp rod holding socket
- Move brass nuts on lamp rod and re-secure
- Change lamp rod length

LED MR16 lamp (12 volt)

- Position LED just above design space for max light spread, OR position higher to reduce glare
- Single LED lamp for best shadow patterns
- LED option; replace socket with LED block

15" custom cap

Set screws (2 - 3/8" stainless steel - use 3/16" hex key) secure cap with tabs fitting inside column top

Cap outlines

Socket assembly mounting strap (stainless)  
 - Screws secure strap inside fixture on tabs  
 - Maintenance: lubricate screws at lamp change

Anti glare options; acrylic insert (clear or frosted) or "snoot" plate insert rest on blocking

**Spire (9x9) - Installation**  
 See About page - "Concrete Piers"

Aspen Design

**Attraction Lights**  
[www.AttractionLights.com](http://www.AttractionLights.com)  
[info@attractionlights.com](mailto:info@attractionlights.com)  
 970-316-0019

Corner tube routes lead wires to base

Wire connections housed in base

**Base Plate Assembly:**

- Secures and levels fixture on concrete pier
- See About page - "Concrete Piers"

**Lifetime Guarantee Void** if soil covers base plate - cover concrete pier with mulch

1/2 x 12" galvanized anchor bolts

False bottom plate option  
 - Maintenance: remove any accumulated debris

Set screws (4 - 3/8" stainless - use 3/16" hex key ) secure obelisk body to base plate  
 - Maintenance: lubricate threads periodically

Concrete Pier: (12" diameter, depth varies)  
 - See About page - "Concrete Piers"  
 - Hardware, template and instructions supplied

"L" (1") conduit routes wires into obelisk base